



Corp Cap STYLE CCAP

INSTALLATION INSTRUCTIONS

- 1) Verify pipe O.D. and saddle range to ensure proper part is being installed.
- 2) Thoroughly clean pipe surface to be covered by Cap Saddle.
- 3) Lubricate the saddle gaskets to allow proper seating and compression.
- 4) Make a mark on the main pipe near the center line of the current corporation fitting to ensure proper alignment is maintained during installation.
- 5) Place the Cap Saddle over the corporation fitting using the marking on the pipe as a guide.
- 6) Hand-tighten all nuts to snug while maintaining the Cap Saddle in its proper location.
- 7) Begin to tighten all nuts down in a crisscross pattern, in order to prevent saddle from pulling in one direction or the other.

MAINTAIN EVEN GAP BETWEEN SHELLS

NOT FOR USE ON HDPE PIPE

Nominal Pipe Size	Thin Wall PVC	C900/905	RIGID (DI,
4 – 8	50-65 ft.-lbs.	70-90 ft.-lbs.	75-100 ft.-lbs.
10 – 24	65-80 ft.-lbs.	75-100 ft.-lbs.	85-125 ft.-lbs.
<i>Not listed</i>	<i>Consult Factory</i>		